

# People Counter Dashboard

## Inhaltsverzeichnis

1 Prepare KBOX A-330-RPI .....	1
1.1 Download image .....	1
1.2 Copy image to the Micro SD Card .....	2
2 Setup XOVIS cameras .....	2
2.1 Add XOVIS cameras .....	2
2.2 Change camera credentials .....	3
2.3 Delete API cameras. ....	3
2.4 Additional field designations. ....	4
3 Setup Dashboards .....	4
3.1 Add Dashboard. ....	4
3.2 Change Dashboard credentials .....	6
3.3 Delete Dashboard. ....	7
4 Setup Executable Devices .....	7
4.1 Add Executable Devices .....	7
4.2 Change Executable Device credentials .....	8
4.3 Delete Executable Device .....	8
4.4 Additional field designations. ....	9
5 Setup Output Signals of Executable Device .....	9
5.1 Add Output Signals .....	9
5.2 Change Output Signals credentials .....	10
5.3 Delete Output Signals .....	11
6 Upload files to the server .....	11
6.1 Add Files. ....	11
6.2 Show uploaded image files. ....	12
6.3 Delete Files. ....	12
7 Users .....	12
7.1 Add a user .....	12
7.2 Change user credentials .....	13
7.3 Remove a user .....	13
8 Change browser configuration .....	14
8.1 Reload browser configuration. ....	14
9 Network .....	14
9.1 Network Setup. ....	14

## Prepare KBOX A-330-RPI

### Download image

Version	Download Link
1.3.0.1	<a href="http://nas0.dnsalias.com:5000/sharing/wZzteL0s7">http://nas0.dnsalias.com:5000/sharing/wZzteL0s7</a>

## Copy image to the Micro SD Card

1. Download an image from the table above
2. Extract an archive
3. Use utility **HDDRawCopy1.10Portable** from the archive to copy the image on the Micro SD Card


## Setup XOVIS cameras

### Add XOVIS cameras


1. To add a new XOVIS camera, you firstly need to select the **Devices/ Geräte** tab.




2. Click on the **Add/ Hinzufügen** button.




3. Here you should specify the camera URL.

A screenshot of a form field labeled 'Kamera Url \*'. The input field contains the text 'http://192.168.1.45'.


4. Specify a login to access the camera.

A screenshot of a form field labeled 'Anmeldung \*'. The input field contains the text 'test'.


5. Specify a password to access the camera.

A screenshot of a form field labeled 'Passwort \*'. The input field contains the text 'test'.

6. In this field specify the URL of your server (this field will be used for PUSH notification configuration on the camera side).

A screenshot of a form field labeled 'Push-Server-Url \*'. The input field contains the text 'http://localhost:3030'.


7. Save it.



A screenshot of a form with two buttons: a green 'Speichern' button with a checkmark icon and a blue 'Abbrechen' button with an 'X' icon. The 'Speichern' button is highlighted with a red box.


## Change camera credentials

1. If you want to change camera data just click on the camera list area.



A screenshot of a camera list area. It shows a checkbox labeled 'Kamera Url' and a row with a checkbox and the text 'demo'. The 'demo' row is highlighted with a grey background.


2 Then click on the **Edit/ Bearbeiten** button.



A screenshot of a form with two buttons: a blue 'Bearbeiten' button with a pencil icon and a red 'Löschen' button with a trash can icon. The 'Bearbeiten' button is highlighted with a red box.

3. After that you can change camera data.

4. And save changes.




A screenshot of a form with two buttons: a green 'Speichern' button with a checkmark icon and a blue 'Abbrechen' button with an 'X' icon. The 'Speichern' button is highlighted with a red box.

## Delete API cameras.


### HINWEIS

Be careful! Do not remove cameras that are used.

1. To remove unwanted cameras, mark them.




2. Click on the Delete/ Löschen button.



A screenshot of a form with two buttons: a blue 'Hinzufügen' button with a plus icon and a red 'Löschen' button with a trash can icon. The 'Löschen' button is highlighted with a red box.


## Additional field designations.

The status icon shows the connection to the camera. If it is green then the connection exists, if it is red then no connection exists.




A screenshot of a form field labeled 'Kamera Url'. The field contains the text 'demo' and is preceded by a small square icon.

The status connection you can see also if you just click on the camera list area.




A screenshot of a form field labeled 'Status'. The field contains the text 'keine Verbindung'.

This field shows the connection error.



A screenshot of a form field labeled 'Verbundene Fehlermeldung'. The field contains the text 'unknown url type: 'demo/api/info''.

MAC camera address. It is automatically filled in by the server.



A screenshot of a form field labeled 'MAC'. The field contains the text 'ff:ff:ff:ff:ff:ff'.

## Setup Dashboards

### Add Dashboard.


1. Add a new dashboard, you firstly need to go to Dashboard.



A screenshot of a navigation menu with the 'wanzl' logo and the following items: 'Zuhause', 'Geräte', 'Dashboard', and 'System'. The 'Dashboard' item is highlighted with a red box.

2. Select the Dashboards tab.

3. And then click on the **Add/ Hinzufügen** button.



A screenshot of a button labeled 'Hinzufügen' with a plus sign icon, next to a 'Löschen' button with a trash icon. The 'Hinzufügen' button is highlighted with a red box.

4. Enter here the name of the area.

	Name *
	<input type="text" value="Test"/>

5. Here you should specify a unique name without spaces and starts with a lowercase letter. This is a service field. For example: If you specified the name "Test", you can specify a unique name "test".

	Eindeutiger Name *
	<input type="text" value="test"/>

6. Here you can select a theme for the area display. For example:

	Vorlage
	<input type="button" value="Wählen Sie das Vorlage"/>

7. Here you can choose the background for the "Basic" theme. If you want to add an image, you should upload it up to the server. More details on the link [upload files](#)

	Hintergrundbild
	<input type="text" value="background_wanzl.jpg"/>

8. This field can be used in case if you want to specify an Offset for counter(for example when people are already in the area, but camera's counter is zero).

	Zähler-Offset
	<input type="text" value="0"/>

9. Click on the **Add/ Hinzufügen** button to add a camera.

	<input type="button" value="Hinzufügen"/>
--	---

10. Select the camera that was added earlier. If you do not know how to add a camera to click on this link [setup XOVIS cameras](#)

11. Choose the detect type.

12. Enter the name line.

	Kamera ▾	Typ erkennen ▾	Name der
	<input type="text" value="demo"/>	<input type="text" value="Line"/>	<input type="text" value="Line 0"/>

13. Here we specify the maximum capacity of the number of people.

Kapazität *
10

14. Here you can specify the schedule restart counter time. If you need to specify more than 2 values, be sure to separate them with a semicolon.

Zeitplan für das Zurücksetzen des Zählers
06:00;18:00

**If you need to change the text translation on Dashboard by interval:**

15. To add the ability to select a language, click the **Add/ Hinzufügen** button as many times as you need the languages.

<input type="button" value="Hinzufügen"/>
---

16. Choose a language.

Sprachen ▾
English
Deutsch

17. Enter the language switching interval in seconds.

Sprach-Timeout(Sec)
10

18. And save it.

<input type="button" value="✓ Speichern"/> <input type="button" value="✗ Abbrechen"/>
---


## Change Dashboard credentials

1. If you want to change dashboard data just click on the dashboard list area.


<input type="checkbox"/> Name
<input type="checkbox"/> Demo

## People Counter Dashboard

2. Then click on the **Edit/ Bearbeiten** button.




3. After that you can change dashboard data. 4. And save changes.




## Delete Dashboard.

1. To remove unwanted Dashboard, mark them.



2. And then click on the **Delete/ Löschen** button.



## Setup Executable Devices


### Add Executable Devices

1. To add a new executable device, you firstly need to select the **Devices/ Geräte** tab.



2. Select the **Executable Devices/ Ausführbare Geräte** tab.

3. And then click on the **Add/ Hinzufügen** button.



4. Select the type of executable device communication protocol.



5. Here you should specify the executable device URL.

	URL-Adresse *
	udp://192.168.1.10:12345

6. And Save it.

	<input type="button" value="✓ Speichern"/> <input type="button" value="✗ Abbrechen"/>
--	---

## Change Executable Device credentials

1. If you want to change executable device data just click on the executable device list area.

	<input type="checkbox"/> Name
	<input type="checkbox"/> udp://192.168.1.10:12345

2. Then click on the **Edit/ Bearbeiten** button.

	<input type="button" value="✎ Bearbeiten"/> <input type="button" value="🗑 Löschen"/>
--	--


3. After that you can change executable device data.

4. And save changes.

	<input type="button" value="✓ Speichern"/> <input type="button" value="✗ Abbrechen"/>
--	---

## Delete Executable Device

1. To remove an executable device, mark them.



2. Be careful! Do not remove an executable device that is used. Click on the **Delete/ Löschen** button.

	<input type="button" value="➕ Hinzufügen"/> <input type="button" value="🗑 Löschen"/>
--	--



## Additional field designations.

**Command Information/ Kommando-Informationen** contains information about commands to control the device.

Kommando-Informationen

- FF0100 - Relay 1 OFF command (ASCII encoding)
- FF0101 - Relay 1 ON command (ASCII encoding)
- FF0200 - Relay 2 OFF command (ASCII encoding)
- FF0201 - Relay 2 ON command (ASCII encoding)
- FF0300 - Relay 3 OFF command (ASCII encoding)
- FF0301 - Relay 3 ON command (ASCII encoding)
- FF0400 - Relay 4 OFF command (ASCII encoding)
- FF0401 - Relay 4 ON command (ASCII encoding)
- FFE000 - All relays OFF command (ASCII encoding)
- FFE003 - All relays ON command (ASCII encoding)

## Setup Output Signals of Executable Device

### Add Output Signals

1. To add new output signals, you firstly need to select the **Devices/ Geräte** tab.

 Zuhause **Geräte** Dashboard System

2. Select the **Output Signals/ Ausgangssignale** tab.

3. And then to click on the **Add/ Hinzufügen** button.

4. Enter here the name of the output signals.

Name \*

5. Here you should select an area.

Bereich \*

6. Here you should choose the executable device URL.

	Ausführbare Gerät *
	udp://192.168.1.10:12345

7. Insert the command of a high level of the executable device.

	Hochrangiger Befehl ⓘ
	FF0101

8. Insert the command of a low level of the executable device.

	Befehl auf niedriger Ebene ⓘ
	FF0100

9. Here you can specify transition delay time.

	Impulszeit, ms
	0

10. This field is necessary to specify the condition of relay triggering.

	Bedingung *
	capacity <= count

11. Save it.

	<input type="button" value="✓ Speichern"/> <input type="button" value="✗ Abbrechen"/>
--	---

## Change Output Signals credentials

1. If you want to change output signals data just click on the output signals list area.


	<input type="checkbox"/> Name
	<input type="checkbox"/> Test

2. Then click on the **Edit/ Bearbeiten** button.

	<input type="button" value="✎ Bearbeiten"/> <input type="button" value="🗑 Löschen"/>
--	--


3. After that you can change its data.

4. And save changes.




## Delete Output Signals

1. To remove unwanted Output Signals, mark them.



2. Click on the **Delete/ Löschen** button.



## Upload files to the server


### Add Files.

1. Add a new area, you firstly need to go to Dashboard.




2. Select the **Image Assets/ Bild-Assets** tab.

3. And then click on the **Add/ Hinzufügen** button and select a file on your file system. If a file is uploaded to the server, you can see it in the file list.



## Show uploaded image files.

1. If you want to see image files just click on the file list area.




## Delete Files.


### HINWEIS

Be careful! Do not remove files that are used.

1. To remove unwanted files on the server, mark them. Preset files can't be deleted.



2. And then click on the **Delete/ Löschen** button.



## Users


### Add a user

1. To add a new user, you firstly need to select the System tab.



2. Click on the **Users/ Benutzer** tab.

3. Then click on the **Add/ Hinzufügen** button.



## People Counter Dashboard

4. In this field you should specify **Login/ Anmeldung** for a new user

	Anmeldung *
	user1

5. In this field you should specify **Password/ Passwort** for a new user

	Passwort
	testpassword

6. If you want to grant the user administrator rights, tip this field. (Administrative rights give rights to edit, create, delete and view. And the standard rights only to view.)

	<input type="checkbox"/> Admin *
--	----------------------------------

7. Click on the **Save/ Speichern** button to complete the adding of a new user.

	<input type="button" value="✓ Speichern"/> <input type="button" value="✗ Abbrechen"/>
--	---

## Change user credentials

1. If you want to change user data just click on the user list area.

	<input type="checkbox"/> <b>Anmeldung</b>
	<input type="checkbox"/> admin

2. Then click on the **Edit/ Bearbeiten** button.

	<input type="button" value="✎ Bearbeiten"/> <input type="button" value="🗑 Löschen"/>
--	--

3. After that you can change user data. 4. And save the changes.


	<input type="button" value="✓ Speichern"/> <input type="button" value="✗ Abbrechen"/>
--	---

## Remove a user


### HINWEIS

Be careful! Do not remove users that are used.

1. To remove unwanted user, mark them. Preset files can't be deleted.



2. And then click on the **Delete/ Löschen** button.



## Change browser configuration


Reload browser configuration.

1. To display, you firstly need to go to **System**.




2. Select the **Display/ Bildschirm** tab.

3. If you need a mouse cursor to be displayed in the kiosk, tip this field.



4. Enter the display URL.



5. Then click on the **Reload** button.



## Network

Network Setup.

1. To configure or view the network settings, you firstly need to go to **System**.




## People Counter Dashboard

2. Select the **Network** tab.

There are two methods of network configuration.


The first method:

- Tip the field.



A screenshot of a network configuration form. On the right side, there is a checkbox labeled "DHCP" which is checked with a blue checkmark.


- Then click on the \*Reload\* button. And the DHCP server will automatically give the necessary settings.



A screenshot of the same network configuration form. A green button labeled "Reload" is highlighted with a red rectangular box.


The second method:

- Specify an IP address.




A screenshot of a network configuration form. The "Address \*" field is filled with the IP address "192.168.1.66".

- Enter netmask.




A screenshot of a network configuration form. The "Netmask \*" field is filled with the netmask "255.255.255.0".

- Input address of the gateway.




A screenshot of a network configuration form. The "Gateway \*" field is filled with the IP address "192.168.1.1".

- Now fill in the DNS IP address.



A screenshot of a network configuration form. The "DNS Server \*" field is filled with the IP address "8.8.8.8".

- And then click on the \*Reload\* button.



A screenshot of the same network configuration form. A green button labeled "Reload" is highlighted with a red rectangular box.