

Gate ~ FMCU ~ management dashboard/en



Inhaltsverzeichnis

1 General	2
2 Sign Up	2
3 Headline	2
4 Menu items	3
4.1 Facilities	3
4.1.1 Gate-View	6
4.1.2 Set up a new Gate	7
4.1.3 Edit existing Gate	12
4.1.4 Remove Gate	15
5 Administration	18
5.1 User	18
5.1.1 Set up new User	19
5.1.2 Edit existing User	19
5.1.2.1 Event Notifications	20
5.1.2.2 Locations & Positions Tab	20
5.1.2.3 Groups Tab	20
5.1.2.4 Permissions Tab	21
5.2 Groups	22
5.2.1 Set up new Group	22
5.2.2 Edit existing Group	23
5.2.2.1 Users Tab	23
5.2.2.2 Permissions Tab	23
5.3 Positions	23
5.3.1 Set up new Position	23
5.3.2 Edit existing Position	23
5.4 Locations	24
5.4.1 Set up new Location	24
5.4.2 Edit existing Location	24
5.5 Locations & Positions	24
5.6 Configuration	24
6 Events	25
6.1 Events	25
6.2 Event Definitions	25
6.3 Event definition Groups	26
6.3.1 Create a new Event definition Group	26
6.4 Event Subscriptions	27
6.5 Notifications	27
7 Cards	28
7.1 Cards	28


7.2 Edit Cards	28
8 Statistics	29

General


The Wanzl Access Manager offers a central dashboard for access controls in a homogeneous interface, displays the corresponding states and supports the user in the administration of these components. The Wanzl Access Manager is a leading platform for monitoring and managing access controls of security areas.

Sign Up

Please enter the login information provided by support here to log in to the central dashboard.



Headline



Number	Function
1	Button Management Dashboard
2	Administration
3	Events Button
4	Cards Button
5	Statistics Button


6	Logged in User
7	Log out Button
8	Languages menu
9	Adjust the display to entire width of the screen

Menu items


Facilities

```
https://<dns-name or ip-address>/gates
```

In this view, all access controls are displayed in an intuitive interface. There are grouping options in two categories. First, you can group by **Location**. Within the location you can then summarize different **Locations**. Individual gates can be added via the menu item "New".



When the light view is off, the access controls are shown in the list.








The screenshot shows the Wanzl management interface. At the top, there are navigation tabs: Facilities, Administration, Events, Cards, and Statistics. The user is logged in as 'admin' and the language is set to English. Below the navigation, there is a 'Facilities' section with a 'New' button and a 'Grid View' toggle (highlighted with a red box and a hand icon). There are also dropdown menus for 'Location' and 'Position'. Below these are control buttons for 'Normal', 'Lock', 'Entry', 'Exit', 'Clearance', and 'Emergency'. The main area displays a table of facilities:

Name	Position	Location	Mode	Alarm	Clear.	Lock.	Facility
P1_GG1	P1	Standort	Normal	👍	👎	👍	Gate is disconnected
P1_GG2	P1	Standort	Normal	👍	👎	👍	Gate is disconnected
P1_GG3	P1	Standort	Normal	👍	👎	👍	Gate is disconnected
P1_TestGate	P1	Standort	Normal	👍	👎	👍	Gate is disconnected
P1_TestGate2	P1	Standort	Normal	👍	👎	👍	Gate is disconnected








When one or more facilities are selected with the control,













the facilities can be controlled with the following buttons:

Symbol	Description	Note
	change to normal state, lock the doors in both directions	
	open the door permanently or open it for a single person	towards the entrance
	open the door permanently or open it for a single person	toward the exit
	Turn the Cleaning mode on and off	cleaning
	Toggle Emergency Open mode on and off	Emergency

The Gate display contains the following controls:


Symbol	Description	Note
	choose the gate	to activate the buttons above (Normal, Lock Out , etc.)
P1_GG1	Navigate to the Facilities page	
	Navigate to the page Gate-View	
	change to Normal state	
	lock the doors in both directions	
	open the door in the direction of entrance/exit for a single person	
	lock the door in the direction of entrance/exit	
	permanently open the door in the direction of entrance/exit	

The symbols under the gate convey various information about it:

Symbol	Description	Note
	No connection to the gate	
	The gate is in the Normal state	
	The gate is in the Locked state	
	The gate is in the fire alarm state	
	The gate is in the emergency open state	
	The cleaning mode is active	
	Alarm is active at the gate	
	The gate is permanently open	
	One or more devices at the gate have failed	
	Current selected configuration of the gate	Only if there are two or more configurations at the gate





Gate-View

In this view, you can observe the state of each gate, control the gate, and apply the gate's configurations (if there are two or more).



The screenshot shows the 'Gate-View' for 'P1_GG1, P1'. At the top, there is a navigation bar with 'wanzl' logo, 'Facilities', 'Administration', 'Events', 'Cards', and 'Statistics' tabs. On the right, it shows 'admin', 'Sign out', and 'English' language selection. Below the navigation bar, the breadcrumb 'Facilities > Gate View' is visible. The main content area features a central gate diagram with buttons for 'Single Free', 'Lock', and 'Open Service' on both sides. To the right of the diagram are 'Clearance' and 'Emergency' toggle switches, both currently off, and a red 'Restart' button. Below the diagram are 'Normal' and 'Lock' buttons. At the bottom left, a 'Disconnected' status indicator is shown.



These buttons allow you to perform various actions:

Symbol	Description	Note
Clearance 	Turn cleaning mode on and off	
Emergency 	Manually switch the emergency open state on and off	
	Restart the gate	
Konfiguration: 	Choose a new configuration of the gate from the combo box	Only if there are two or more configurations at the gate

<div style="border: 1px solid blue; padding: 5px; display: inline-block;">Anwenden</div>	Apply the new configuration
<div style="border: 1px solid gray; padding: 5px; display: inline-block;">Abbrechen</div>	Do without the new configuration

Set up a new Gate

Please click the button **New**

wanzl Facilities Administration ▾ Events ▾ Cards ▾ Statistics admin ↗ Sign out  English 

Facilities

New

Grid View
Location:
Position:

Normal
Lock

Entry:
Lock
Open Service
Single Free


Exit:
Lock
Open Service
Single Free


Clearance:
On
Off

Emergency:
On
Off


Select All
-
Scale
+
0 / 6


P1

P1_G... 





Disconnected

P1_G... 





Disconnected

P1_G... 





Disconnected

P1_T... 





Disconnected

P1_T... 



Disconnected

TestG... 



Disconnected

In this view you create a **New** gate. The fields **Names**, **Displayed Name** and **Position** of the Gate must be verified with values. Press Save then click on Facilities.

wanzl Facilities Administration Events Cards Statistics admin Sign out English

Facilities > New Gate

Id: []

Name: TestGate_P1

Display name: TestGate_P1

Position: P1

Disable notifications:

Locked:

Save Cancel New Delete

Cards

Edit

wanzl Facilities Administration Events Cards Statistics admin Sign out English

Facilities > Facility

Id: 12

Name: TestGate_P1

Display name: TestGate_P1

Position: P1

Disable notifications:

Locked:


Save Cancel New Delete

Cards

Barcode	Employee	Count

Edit


You can now see in the view that you have created a **NEW** gate, in this case the sixth gate in this view.



In the next step you connect the gate to the server.

<https://<IP-Adresse des Dashboards>>

To do this, check on the **General** tab that the correct gate name has been entered.



Then check the following points on the **Server** tab.

wanzi Home Dashboard Status **Configuration** System WEAC Files Statistics guest [Sign out](#) English

[Save to File](#) [Load from File](#) [Reset](#)

[General](#) [Devices](#) [Alarms](#) [Signals](#) [Output Signals](#) [Dispatchers](#) [Displays](#) **Server** [Diamex Update](#) [Configuration Type](#)

[Save](#) [Cancel](#) 1 / 1

ServerRemote

Remote

Enabled

Interlock

Gate's own URL (e.g. http://localhost:8888)

Pause after connection failure, seconds *

Name *

Server#0 (server)- must be set to remote.

Activated slide-switch is activated.

Your server should be entered under Name*.


Your URL should be entered under URL*.

Gate should be entered under Username*.

Your password should be entered under Password*.


Save at the end.

In the next step, please click on System in the top bar.



The screenshot shows the WANZI management dashboard. The top navigation bar includes 'Home', 'Dashboard', 'Status', 'Configuration', 'System', 'WEAC', 'Files', and 'Statistics'. The 'System' tab is active, and a red arrow points to it. Below the navigation bar are buttons for 'Save to File', 'Load from File', and 'Reset'. A secondary navigation bar contains 'General', 'Devices', 'Alarms', 'Signals', 'Output Signals', 'Dispatchers', 'Displays', 'Server', 'Diamex Update', and 'Configuration Type'. The 'Server' tab is selected. Below this are 'Save' and 'Cancel' buttons, and a pagination indicator '1 / 1'. The main content area is titled 'ServerRemote' and contains a dropdown menu set to 'Remote', an 'Enabled' toggle switch (checked), an 'Interlock' toggle switch (unchecked), a text input field for 'Gate's own URL (e.g. http://localhost:8888)', a numeric input field for 'Pause after connection failure, seconds *' set to '5', and a text input field for 'Name *' set to 'Server #0'.

You will now see the following display, here please press restart once. Now your new gate should be connected.



The screenshot shows the WANZI management dashboard with the 'System' tab active. The 'Hardware' sub-tab is selected. At the top right, there are 'Restart' and 'Reboot System' buttons, with a red arrow pointing to the 'Restart' button. Below the navigation bar are buttons for 'Save' and 'Reset', and status indicators for 'Dirty', 'Invalid', and 'Simulator'. Below these are buttons for 'Network', 'OpenVPN', 'USB Devices', 'Hardware', and 'Update Software'. A 'Refresh' button is located above a terminal window. The terminal window displays the following output:

```
# lsusb
Stderr:
unable to initialize libusb: -99

# ls /dev/input/by-id
Stderr:
ls: /dev/input/by-id: No such file or directory

# find /dev -name ttyUSB* -o -name ttyACM*
```

Finally, you can check the connection in the **Status** tab. **CONNECTED** must now appear under State.

wanzi Home Dashboard **Status** Configuration System WEAC Files Statistics guest [Sign out](#) English

Server

Type	Last Error	State	Action
Simulator		Connected	Connection error

Displays

Display Entry	https://gate.maxcrc.de/display/display_entry
Display Exit	https://gate.maxcrc.de/display/display_exit

Devices

Name	Type	State	Failure Reason	Failure
GateModbusGalaxyGateTcp	GateModbusGalaxyGateTcp	Failure	Unit 1: No connection, Unit 2: No connection	<input checked="" type="checkbox"/>
Light Bar	Simulator	Ready		<input type="checkbox"/>
Audio Player	Simulator	Ready		<input type="checkbox"/>
Slave FMCU	Simulator	Ready		<input type="checkbox"/>
Led Player	Simulator	Ready		<input type="checkbox"/>
Led Player	Simulator	Ready		<input type="checkbox"/>

Edit existing Gate

`https://<dns-name or ip-address>/gates`

You are in the same view as where you would create a new gate.

Please move the slide switch "Grid view" to the left.

wanzl Facilities Administration Events Cards Statistics admin Sign out English

Facilities

New Grid View Location: Select locations Position: Select positions

Normal Lock Entry: Lock Open Service Single Free Exit: Lock Open Service Single Free Clearance: On Off Emergency: On Off

<input type="checkbox"/>	Name	Position	Location	Mode	↑	✂	⚙	☰	Alarm	Clear.	Lock.	Facility
<input type="checkbox"/>	P1_GG1	P1	Standort	Normal	👍	⊖	👍					
Gate is disconnected												
<input type="checkbox"/>	P1_GG2	P1	Standort	Normal	👍	⊖	👍					
Gate is disconnected												
<input type="checkbox"/>	P1_GG3	P1	Standort	Normal	👍	⊖	👍	👍				
Gate is disconnected												
<input type="checkbox"/>	P1_TestGate	P1	Standort	Normal	👍	⊖	👍	👍				
Gate is disconnected												
<input type="checkbox"/>	P1_TestGate2	P1	Standort	Normal	👍	⊖	👍					
Gate is disconnected												
<input type="checkbox"/>	TestGate_P1	P1	Standort									
Gate is disconnected												

In the view click on the name of the gate which you want to edit (in the example TestGate_P1).

wanzl Facilities Administration Events Cards Statistics admin Sign out English

Facilities

New Grid View Location: Select locations Position: Select positions

Normal Lock Entry: Lock Open Service Single Free Exit: Lock Open Service Single Free Clearance: On Off Emergency: On Off

Name	Position	Location	Mode	Alarm	Clear.	Lock.	Facility
<input type="checkbox"/> P1_GG1	P1	Standort	Normal				
Gate is disconnected							
<input type="checkbox"/> P1_GG2	P1	Standort	Normal				
Gate is disconnected							
<input type="checkbox"/> P1_GG3	P1	Standort	Normal				
Gate is disconnected							
<input type="checkbox"/> P1_TestGate	P1	Standort	Normal				
Gate is disconnected							
<input type="checkbox"/> P1_TestGate2	P1	Standort	Normal				
Gate is disconnected							
<input type="checkbox"/> TestGate_P1	P1	Standort					
Gate is disconnected							

In this view, please press the "Edit" function.

wanzl Facilities Administration Events Cards Statistics admin Sign out English

Facilities > Facility

Id: 12

Name: TestGate_P1

Display name: TestGate_P1

Position: P1

Disable notifications:

Locked:

Save Cancel New Delete

Cards

Barcode	Employee	Count
<input type="button" value="Edit"/>		

You can now edit the gate in this view.

wanzl Facilities Administration Events Cards Statistics admin Sign out English

Facilities > Gate Cards

TestGate_P1
P1, Standort
Disconnected

Barcode	Employee	Employee ID	Count
---------	----------	-------------	-------

Save Cancel New Teaching Mode Save to File Load from File < >

Remove Gate

`https://<dns-name or ip-address>/gates`

You are in the same view as where you would create a new gate.

Please move the slide switch "Grid view" to the left.

wanzl Facilities Administration Events Cards Statistics admin Sign out English

Facilities

New **Grid View** Location: Select locations Position: Select positions

Normal Lock Entry: Lock Open Service Single Free Exit: Lock Open Service Single Free Clearance: On Off Emergency: On Off

Name	Position	Location	Mode	Alarm	Clear.	Lock.	Facility
<input type="checkbox"/> P1_GG1	P1	Standort	Normal	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Gate is disconnected							
<input type="checkbox"/> P1_GG2	P1	Standort	Normal	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Gate is disconnected							
<input type="checkbox"/> P1_GG3	P1	Standort	Normal	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Gate is disconnected							
<input type="checkbox"/> P1_TestGate	P1	Standort	Normal	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Gate is disconnected							
<input type="checkbox"/> P1_TestGate2	P1	Standort	Normal	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Gate is disconnected							
<input type="checkbox"/> TestGate_P1	P1	Standort	Normal	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Gate is disconnected							

In the view click on the name of the gate which you want to delete (in the example TestGate_P1).

wanzl Facilities Administration Events Cards Statistics admin Sign out English

Facilities

New Grid View Location: Select locations Position: Select positions

Normal Lock Entry: Lock Open Service Single Free Exit: Lock Open Service Single Free Clearance: On Off Emergency: On Off

Name	Position	Location	Mode	Alarm	Clear.	Lock.	Facility
<input type="checkbox"/> P1_GG1	P1	Standort	Normal				
Gate is disconnected							
<input type="checkbox"/> P1_GG2	P1	Standort	Normal				
Gate is disconnected							
<input type="checkbox"/> P1_GG3	P1	Standort	Normal				
Gate is disconnected							
<input type="checkbox"/> P1_TestGate	P1	Standort	Normal				
Gate is disconnected							
<input type="checkbox"/> P1_TestGate2	P1	Standort	Normal				
Gate is disconnected							
<input type="checkbox"/> TestGate_P1	P1	Standort					
Gate is disconnected							

In this view, please press the "Delete" function.

wanzl Facilities Administration Events Cards Statistics admin Sign out English

Facilities > Facility

Id: 12

Name: TestGate_P1

Display name: TestGate_P1

Position: P1

Disable notifications:


Locked:

Save Cancel New Delete


Cards

Barcode	Employee	Count
<input type="button" value="Edit"/>		

To be on the safe side, you will now be asked again whether you really want to delete the element? Please confirm this.



After deleting, you will automatically be shown the next gate (in the example P1_TestGate2). Please click on Facilities here.



You will then see in the Grid View that Gate TestGate_P1 is missing and has been successfully deleted.

wanzi Facilities Administration Events Cards Statistics admin Sign out English

Facilities

New Grid View Location: Select locations Position: Select positions

Normal Lock Entry: Lock Open Service Single Free Exit: Lock Open Service Single Free Clearance: On Off Emergency: On Off

Name	Position	Location	Mode	Alarm	Clear.	Lock.	Facility
<input type="checkbox"/> P1_GG1	P1	Standort	Normal				
Gate is disconnected							
<input type="checkbox"/> P1_GG2	P1	Standort	Normal				
Gate is disconnected							
<input type="checkbox"/> P1_GG3	P1	Standort	Normal				
Gate is disconnected							
<input type="checkbox"/> P1_TestGate	P1	Standort	Normal				
Gate is disconnected							
<input type="checkbox"/> P1_TestGate2	P1	Standort	Normal				
Gate is disconnected							

Administration

User

`https://<dns-name or ip-address>/users`

On this page you can see an overview of all users

wanzi Facilities Administration Events Cards Statistics admin Sign out English

Users

New Location: Select locations Position: Select positions

Username	First Name	Last Name	Locations & Positions	Groups	Super.	Lock.	Delete
admin					<input checked="" type="checkbox"/>		
gate			Standort All positions	gate			
user			Standort All positions	user			
			Standort P1				


Number	Function
1	Create new user
2	Filter users by location

3	Filter users by position
---	--------------------------

Set up new User

Press under [User](#) on the button **New**

`https://<dns-name or ip-address>/new-user`



Users

New Location: Position:

Username	First Name	Last Name	Locations & Positions	Groups	Super.	Lock.	Delete
admin					✓		
gate			Standort	All positions			
user			Standort	All positions			
			Standort	P1			

Field Name	Description
Id	Automatically generated unique number of the user
Username*	Username of the user to login
Password*	User's password for login
Email	Email address of the user for sending log messages
First name	User's first name
Last name	Last name of the user
Info	Description of the user
Superuser	The highest rights are assigned to the user
Locked	The user's login is blocked
Disable notifications	The user does not receive any notifications in the FMCU Management Dashboard

* Strictly required fields Through the button **Save** the new user is created.

Edit existing User

Press under [User](#) a user to edit

wanzl Facilities Administration Events Cards Statistics admin Sign out English

Users

New Location: Select locations Position: Select positions

Username	First Name	Last Name	Locations & Positions	Groups	Super.	Lock.	Delete
admin					✓		
gate			Standort All positions	gate			
user			Standort All positions	user			
			Standort P1				

Event Notifications

Under this tab, the notifications can be selected which the user should receive.

Note: If the checkbox **Disable notifications** is set, no notifications are displayed regardless of these settings.

wanzl Facilities Administration Events Cards Statistics admin Sign out English

Notifications

Custom Today Yesterday Feb 24, 2022 - Feb 24, 2022 Change 0 / 0

Search...

Date	Recep	Email	Text	Failure
No data to display				

Locations & Positions Tab

You can set different locations in countries and cities. Separate access rights can be defined for each location via the authorization model.

wanzl Facilities Administration Events Cards Statistics admin Sign out English

Locations & Positions

Location	Position
Standort	All positions
Standort	P1

Groups Tab

This tab allows you to customize the user's group memberships.

wanzi Facilities Administration Events Cards Statistics admin Sign out English

Groups

New

Name	Info	Delete
manager		
user		
gate		
alarm_notifications		

Press on the user of that you want to customise the group

wanzi Facilities Administration Events Cards Statistics admin Sign out English

Groups

New

Name	Info	Delete
manager		
user		
gate		
alarm_notifications		

Permissions Tab

The user's permissions are displayed under this tab
All changes are applied by clicking the **Save** button.

wanzi Facilities Administration Events Cards Statistics admin Sign out English

Groups > Group

Id: 2

Name: user

Info:

Save Cancel New Delete < >


Users Permissions



Name

Groups

<https://<dns-name or ip-address>/groups>

On this page you can see an overview of all groups


 Anlagen Administration ▾ Ereignisse ▾ Karten ▾ Statistik

 admin ↗ Abmelden  Deutsch 

Gruppen

Neu


Name	Info	Löschen
manager		
user		
gate		
alarm_notifications		

Set up new Group

<https://<dns-name or ip-address>/new-group>

Click under [Gruppen](#) the button **New**


 Anlagen Administration ▾ Ereignisse ▾ Karten ▾ Statistik

 admin ↗ Abmelden  Deutsch 

Gruppen > Neu Gruppe

Id
 Name
 Info

Benutzer [Berechtigungen](#)

Benutzername	Email	Vorname	Nachname	Info
--------------	-------	---------	----------	------

Field Name	Description
Id	Automatically generated unique number of the group
Name	Name of the Group

Info	Description of the Group
------	--------------------------

* Strictly required fields

The new group is created by clicking the **Save** button.

Edit existing Group

Click under [Gruppen](#) the Group you want edit

Users Tab

This tab allows you to customize the members of the group.

Permissions Tab

The permissions that are inherited by the members of the group are displayed under this tab.
All changes are applied by clicking the **Save** button.

Positions

```
https://<dns-name or ip-address>/cities
```

On this page you can see an overview of all positions

Set up new Position

```
https://<dns-name or ip-address>/new-city
```

Under [Positions](#) click on the button **New** Enter the name of the position and assign the position to a location using the dropdown field. Click on the **Save** button to create the position

Edit existing Position

Under [Positions](#) click to edit the position
Here you can edit the position name and location

Locations

`https://<dns-name or ip-address>/countries`

On this page you can see an overview of all locations

Set up new Location

`https://<dns-name or ip-address>/new-country`

Press under [Locations](#) the button **New**

Field Name	Description
Id	Automatically generated unique number of the location
Name*	Location name
Code*	Location country code
Info	Description of the location

* Strictly required fields

Click on the **Save** button to create the position

Edit existing Location

Under [Location](#) , click the location you want to edit

Here you can edit the name, code and info of the location

Locations & Positions

`https://<dns-name or ip-address>/locations`

Here you can see an overview of all positions and their assigned locations

Configuration


`https://<dns-name or ip-address>/configurations`

Events

Events

`https://<dns-name or ip-address>/events`

In this view, the events of all access controls are shown in an intuitive list view. There are filtering options and a name search for the events.



The screenshot shows the 'Events' management interface. At the top, there is a navigation bar with tabs for 'Anlagen', 'Administration', 'Ereignisse', 'Karten', and 'Statistik'. The 'Ereignisse' tab is active. On the right, there is a user profile 'admin', a language selector set to 'Deutsch', and a logout button 'Abmelden'. Below the navigation bar, there are five numbered filter options: 1. Standort (dropdown), 2. Position (dropdown), 3. Anlage (dropdown), 4. Suche (text input), and 5. Date range (01.02.2021 - 28.02.2021) with an 'Ändern' button. There are also buttons for 'Benutzerdefiniert', 'Heute', 'Gestern', and 'Stop'. A counter shows '39947 / 39947'. Below the filters is a table header with columns: Datum, Name, Anlage, Zu, Ka, Info.

The following filters can be set:

1. Location
2. Position
3. Factory
4. Search by Event name
5. Time Period

Event Definitions

`https://<dns-name or ip-address>/event-definitions`

In this view, all events that the FMCU contains are listed and their event definition groups, supported states and categories are assigned.





The screenshot shows the 'Event Definitions' management interface. It has the same navigation bar as the Events page, with 'Ereignisse' selected. Below the navigation bar, there is a section for 'Ereignisdefinitionen'. A table header is visible with columns: Name, Ereignisdefinitionsgruppen, Unterstützte Zustände, and Kategorie.

Event definition Groups


`https://<dns-name or ip-address>/event-definition-groups`

All event definition groups are listed under this tab.


Anlagen
Administration ▾
Ereignisse ▾
Karten ▾
Statistik
admin
Abmelden
Deutsch




Ereignisdefinitionsgruppen

Neu

Name	Ereignisse	Info	Löschen
Alarm events	<ul style="list-style-type: none"> ServerGateDevicesFailed ServerGateAllDevicesOperational GateUnauthorizedAccess GateStateFireAlarm GateDoorIsBeeingBroken 		

Create a new Event definition Group

Click [Event definition groups](#) on the Button **New**


Anlagen
Administration ▾
Ereignisse ▾
Karten ▾
Statistik
admin
Abmelden
Deutsch


[Ereignisdefinitionsgruppen](#) > New Event Definition Group

Id
 Name
 Info
Speichern Abbrechen Neu Löschen

Ereignisdefinitionen

Name	Info	Kategorie	Ausgewählt
Fieldname	Description		
ID	Automatically generated unique group number		
Name	Name of the group		
Info	Group description		


* Absolutely required fields

Under the **Event definition** tab select the event definitions that are to be assigned to the group.

Event Subscriptions

<https://<dns-name or ip-address>/event-subscriptions>

There is the possibility to link groups of alarm messages with groups of users. As a result, only group members are notified of alarm messages that are also grouped,




Fieldname	Description
ID	internal value
Group	Summary of users
Ereignisdefinitionsgruppe	Event definition group
Locked	Notifications deactivated/activated
Info	Description field

Notifications

<https://<dns-name or ip-address>/notifications>

Sent notifications are displayed in this overview. You can adjust the view accordingly using a date filter.




Cards

Cards

<https://<dns-name or ip-address>/cards>

This view shows an overview of the RFID cards in the system with the gates enabled for access.



Barcode	Mitarbeiter	Anzahl	Gate
number1	number2	1	gate_de_fra
			gate_ma_mar
			gate_de_lan
employee1	employee2	1	gate_de_fra
			gate_ma_mar
			gate_de_lan
test1	test2	1	gate_de_fra
			gate_ma_mar
			gate_de_lan

Edit Cards

<https://<dns-name or ip-address>/cards-edit>

In this view, cards can be added / removed and authorizations for individual gates can be defined.




Barcode	Mitarbeiter	Mitarbeiter ID	Anzahl	Gates	
<input type="checkbox"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	
<input type="checkbox"/>	number1	number2	number3	1	gate_de_fra x gate_ma_mar x gate_de_lan x
<input type="checkbox"/>	employee1	employee2	employee3	1	gate_de_fra x gate_ma_mar x gate_de_lan x

Field	Description
Barcode	Card content that is captured by the reader
Employee	Description field
Employee ID	Description field
Quantity	Number of accesses for this card

Statistics

In this view, all activities for the assigned access controls are shown. You can adjust the view with date filters. It is possible to group the screen output, e.g. only to evaluate the number per day or month. Finally, the data can be exported in Excel format or CSV-format.



The screenshot shows a web interface for a statistics dashboard. It includes several filters and a data table. The filters are: Land (Country) and Stadt (City) dropdown menus, and a Gate dropdown menu. Below these are buttons for time-based filters: Benutzerdefiniert, Heute, Gestern, Diese Woche, Letzte Woche, Diesen Monat, Vorheriger Monat, Zwei vorherige Monate, Drei vorherige Monate, Sechs vorherige Monate, Dieses Jahr, and Vorheriges Jahr. A date range selector shows '01.10.2020 - 31.03.2021' with an 'Ändern' button. There are also buttons for 'Aktualisieren', 'Speichern als csv', and 'Speichern als xlsx'. A 'Gruppierung:' section has buttons for 'Aus', 'Nach Tag', and 'Nach Monat'. The data table below has columns for Datum, Gate, Stadt, Land, Eingang, and Ausgang.

Datum	Gate	Stadt	Land	Eingang	Ausgang
15.10.2020 09:53:54	gate_de_fra	Frankfurt	Germany		No ticket
15.10.2020 09:59:09	gate_de_fra	Frankfurt	Germany	No ticket	
15.10.2020 10:14:19	gate_de_fra	Frankfurt	Germany	Free	
17.11.2020 15:22:19	gate_de_fra	Frankfurt	Germany	No ticket	